Before you begin

Thank you, and congratulations on your choice of the CG-8. This leaflet explains how to switch the CG-8's video output. Please read it before you start using the CG-8.

To use the RGB output

Make the following setting if you want to use the RGB output.

1

Turn on the power of the CG-8.

2

After the CG-8 has started up, hold down the visual pad [1] button and press and hold the [SHUTDOWN] button for at least two seconds to shut down the CG-8.

3

When the CG-8 has finished shutting down and is in standby mode, press the [SHUTDOWN] button once again to restart the CG-8.

4

When the CG-8 restarts, the RGB output will be available for use. This setting will be retained even while the power is switched off.

Using the video output (Composite or S-VIDEO)

Make the following setting if you want to use the video output (Composite or S-VIDEO).

1

Turn on the power of the CG-8.

2

After the CG-8 has started up, hold down the visual pad [2] button and press and hold the [SHUTDOWN] button for at least two seconds to shut down the CG-8.

3

When the CG-8 has finished shutting down and is in standby mode, press the [SHUTDOWN] button once again to restart the CG-8.

4

When the CG-8 restarts, the video output will be available for use. This setting will be retained even while the power is switched off.

* *You can't use the RGB output and video output at the same time.*

Copyright © 2005 ROLAND CORPORATION
All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

* 4 0 6 7 1 1 2 3 - 0 2 *